


BT Socket to RJ11 Adapter


Please note: the RJ11 and RJ10 may look the same but they are different and are not interchangeable. RJ10 would not be suited for use in this setup.



2 FXS/ATA port (receives RJ11 plug)
(only port 1 is configured)



The adaptor is only required where your analogue device has a BT plug:



This advice covers connecting *your analogue device to the router*.
For advice on *connecting-up the router*, refer to DSL Information Sheet or FTTP Information Sheet at <https://www.spitfire.co.uk/about/knowledge-base/>